



# AMERICAN SPECIALTIES, INC.

441 Saw Mill River Road, Yonkers, NY 10701 (914) 476-9000  
www.americanspecialties.com

DOCUMENT: SCCL

ISSUED: 11-05

REVISED: 1-06

## SOAP CARTRIDGE COMPATIBILITY AND LOADING

### Models 5001-SS, 5002

The dispensers are all designed to hold 800 ml bag-in-the-box packages. The length from the box to the nozzle is key. Any other package that has the same dimension from the box to the nozzle should work as long as it fits the cradle and the housing. The nozzle tip must fit the cradle seat.

Sometimes the nozzle is twisted as it comes from the manufacturer [Go-Jo, etc]. The nozzle tip and tube has a rotatable union joint at the bag and can be reoriented to better line up the nozzle retainer rib with the cradle seat.

The nozzle can be held by hand through the lever recess/hole to keep it in the cradle seat while the door is being closed. It is important to close the door properly so the edge engages the housing and the lock can latch properly.

#### TYPICAL MANUFACTURERS AND PRODUCTS THAT FIT UNITS

OTHER SUPPLIERS MAY FIT IF DIMENSIONS ARE THE SAME

Manufacturer	Trade Name	Product Number
GoJo		9102, 9112, 9756
HealthLink	AloeGuard	7720
Kimberly Clark	Sani-Tuff	217007 Rev 001
NetCare	Smooth-n-Soft	8020

#### Procedure for Loading Bag-in-a-Box into typical unit:

1. Load box into unit with nozzle tube facing forward.
2. Pull tube/nozzle all the way out of box after removing cardboard access closure.
3. Orient nozzle to cradle if necessary by twisting tube near bag outlet union.
4. Reach through door opening and push lever back all the way as far as it goes.
5. Seat nozzle into cradle, making sure it stays centered.
6. While holding lever back, close door and lock with key.
7. Check to ensure that nozzle tip remained in cradle.
8. Test operate the unit to ensure proper performance.